How to Chroma Key using a Videonics MX-70 Video Mixer

1. Select **Background source** on the **A Bus (top row)**.
2. Select your **Camera source** on the **B Bus (bottom row)**.
3. Press the **Chroma Key** button on the left side of the Mixer.
4. Press the **Enter** button in the number pad on the right side of the Mixer.
5. Using the **Menu Knobs**, adjust the **Key, Key Color, Slice, Slope, and K-Level**.