

BIOS SETTINGS FOR TABLET PC PEN ALERT

The following instructions describe how to set the BIOS to warn the user when the Tablet PC pen has been left out of the pen holder.

To Access the BIOS setting:

When the computer boots up, **Press the F10 key**

When the BIOS screen appears, perform the following steps:

- Down Arrow Key to <ENTER SETUP>
- Right Arrow to “ADVANCED”
- Down Arrow to “PEN REMINDER ALARM”
- Arrow Up or Down to Select “Enabled”
- Press ENTER
- Press F10 key to SAVE and EEXIT
- Answer “YES” to Save & Exit